



**Missed approach :**  
Climb on runway axis. At 2000 Ft QNH, turn left climbing to 3000 ft QNH to join "DS" VOR. Then join DEPAL via R 176° "DS". Do not turn before MAPt.

CAT	CAT.1				LOC Z				Circling (3)				RVR for take-off			
	OCA (OCH)	DA	DH	RVR(1)	RVR(2)	OCA (OCH)	MDA	MDH	RVR(1)	RVR(2)	OCA (OCH)	MDA	MDH	VIS	CAT A - B - C : 400	CAT D : 400
A	458 (186)	480 (200)	550	1000	574 (302)	580 (310)	900	1500	766 (476)	770 (740)	1500					
B	470 (198)	480 (200)	550	1000	574 (302)	580 (310)	1000	1500	837 (547)	840 (740)	1600					
C	478 (206)	480 (210)	600	1000	574 (302)	580 (310)	1000	1800	947 (657)	950 (830)	2400					
D	489 (217)	490 (220)	600	1000	574 (302)	580 (310)	1400	2000	947 (657)	950 (830)	3600					

Notes : (1) With approach lights - (2) Without approach lights - (3) Daytime only - OCH and MDH AAL

AMDT10/22 : Update