

VAR : 4° W (2020)  
 Variation annuelle : 8.5E





Table des coordonnées des points d'arrêt avant piste (PA) et intermédiaires (PAI)

Type	Taxiway	Latitude	Longitude
PA	A	N005° 14' 56.89"	W003° 55' 54.36"
PA	B	N005° 15' 17.70"	W003° 55' 46.84"
PA	C	N005° 15' 35.73"	W003° 55' 39.36"
PAI	D1	N005° 14' 59.32"	W003° 56' 00.70"
PAI	D2A	N005° 14' 55.47"	W003° 56' 00.31"
PAI	D2B	N005° 14' 56.73"	W003° 55' 57.88"
PA	D3	N005° 14' 54.87"	W003° 56' 01.74"
PAI	D3B	N005° 14' 56.90"	W003° 56' 00.90"
PAI	D32	N005° 14' 48.18"	W003° 56' 07.49"
PA	F	N005° 15' 44.23"	W003° 55' 35.85"
PA	M	N005° 16' 17.78"	W003° 55' 22.06"
PAI	P1	N005° 15' 34.02"	W003° 55' 42.50"
PAI	P2	N005° 15' 47.68"	W003° 55' 36.87"

RWY	DIRECTION	THR	STRENGTH
03	028° (022.5° T)	05°14'55.39"N 003°55'51.75"W	PCN 56 / F / B / W / T
21	208° (202.5° T)	05°16'25.66"N 003°55'14.32"W	PCN 54 / F / B / W / T
			PCN 58 / F / B / W / T
			PCN 25 / F / B / W / T
			PCN 43 / F / A / W / T
			PCN 19 / F / A / W / T
			PCN 43 / F / B / W / T
			PCN 40 / F / B / W / T
			PCN 39 / F / B / W / T
			PCN 67 / F / B / W / T
			PCN 67 / F / B / W / T